

# Qurios

reflections of the future by LALOO



Thank you for purchasing Qurios Component Cabinets.

Please read through these instructions carefully and refer back to them during installation to ensure that your product is installed safely. Your product will retain its high quality finish with proper care and maintenance.

## Care Instructions

To preserve the high quality finish of your Qurios product, please note the following care recommendations.



- Wipe off all water spillages as soon as possible.
- Mirrors and glass can be cleaned with a soft cloth and non-corrosive, non-abrasive brand name cleaner.
- All other surfaces should be cleaned with diluted detergent (i.e. dish soap or hand soap) and a soft cloth. Scourers and scouring agents should not be used, as these may cause damage to the surface of the product.

## Overall Dimensions



**Q20M24**  
Mirror with Shelf  
610 (w) x 762 (h)



**Q2010N**  
Side Cabinet  
310 (w) x 750 (h)



**Q20M24 and Q2010N**  
Mirror and Side Cabinet  
898 (w) x 787 (h)



**Q20M24 and Q2010N**  
Mirror and 2 Side Cabinets  
1186 (w) x 787 (h)

**Q20M30**  
Mirror with Shelf  
760 (w) x 762 (h)

Reversible for  
left or right  
hand installation

**Q20M30 and Q2010N**  
Mirror and Side Cabinet  
1048 (w) x 787 (h)

**Q20M30 and Q2010N**  
Mirror and 2 Side Cabinets  
1336 (w) x 787 (h)

Depth 134

Depth 144

Depth 144

Depth 144

## Warranty

LALOO warrants Qurios Component Cabinets to be free from manufacturing defects in material and workmanship for a period of one year from the date of purchase. This warranty does not cover products improperly installed or subject to improper use or used in a location other than a residential bathroom or products which have been damaged due to mineral deposits or the use of corrosive or abrasive cleaning agents.

This warranty does not cover shipping costs, labour costs or other costs associated with the installation or replacement of the product or part. The warranty is extended only to the original consumer purchaser of the LALOO products.

The original dated sales receipt must be retained by the consumer and is the only acceptable proof of purchase. This warranty gives you specific legal rights and you may also have other rights which may vary from province to province.

## Preparation

- Remove the Mounting Bracket, hardware package and shelf package from the carton.
- Unpack Mirror and/or Cabinet and place on a flat working surface.
- Install shelf to bottom of mirror using screws provided. Ensure that edges of shelf and mirror are flush.
- Establish the location of the component installation considering the overall footprint dimensions on reverse.
- Ensure that the cabinet box is at least 4" from a corner. Ensure that objects do not impede the door swing (ie. faucet).
- *The cabinet door will swing 35mm below the installation base guideline of the mirror.*

## Installing the Mirror

1. Pencil a **horizontal base guideline (B)** for leveling the bottom of the mirror.
2. Mark centre point of the mirror.
3. At mirror centre point draw a plumb **vertical guideline (M)**.
4. Draw a **horizontal guideline (M1)** and centre the bottom of Mounting Bracket on the line.
5. Mark the holes.
6. Install self-tapping wall plugs.
7. Install Mounting Bracket with screws provided.

	<b>B</b> Base Guideline	Centre Point of Mirror	<b>M</b> Vertical Guideline
Q20M24 Mirror Only	610	305	709
Example Q20M24 & Q2010N	876	305	709
Q20M24 & Q2010N (x2)	1142	571	709
Q20M30 Mirror Only	760	380	709
Q20M30 & Q2010N	1026	380	709
Q20M30 & Q2010N (x2)	1292	646	709

## Installing the Cabinet(s)

1. Install the Mirror and ensure that it is level and plumb to all markings.
2. Draw a guideline down the side of the Mirror that will be adjacent to the Cabinet.
3. Remove the Mirror.
4. Measure up **628mm** on the **vertical guideline (C)**.
5. Draw a **133mm horizontal guideline (C1)** from edge of mirror to mark centre point of the Cabinet Mounting Bracket.
6. Place the bottom of Cabinet Mounting Bracket on the line and mark the holes.
7. Install self-tapping wall plugs. Install Mounting Bracket with screws provided.
8. REPEAT STEPS 2 – 6 if you are installing 2 cabinets.

## Stabalizing Cabinet(s)

1. Install Mirror and Cabinet.
2. Check component alignment.
3. Upon satisfactory dry fit, drill pilot hole in cabinet for stabilizing screw. Remove cabinet and install self-tapping wall plugs at pilot hole.
4. Reinstall cabinet and install washer, stabilizing screw and decorative cap.
5. REPEAT STEPS 1 - 4 if you are installing 2 cabinets.

