



# INSTALLATION INSTRUCTIONS

Apply to the below style of LED Backlit Mirrors



Please read carefully and save these instructions.

Don't discard any of the packaging until you are sure that you have all of the parts and the fittings.

## **IMPORTANT**

- Unpack mirror. DO NOT lay mirror on tiled or concrete surface prior to installation. Mirror must be on protected surface to prevent chipping of the corners.
- Care must be taken before drilling pilot holes to avoid any existing wiring or pipe work that may be concealed.

## **INSTALLATION**

Please refer the installation diagram on the back of the page.

- 1) Unpack the LED mirror and prepare tools needed.( See Pic.1 )
- 2) Mark down the screw positions against the wall, hanger and T-shape locking screw on wall.(See Pic.2)
- 3) Drill holes, and put in the plastic plugs, then fix the hanger by screws and use the spanner to lock the locking screw to the wall.(See Pic.3&Pic.4);
- 5) Hanging the LED mirror with hanger, then lock it with locking screw by using the spanner provided at the fittings bag.(See Pic.5&Pic.6)

## **MAINTENANCE**

Wipe clean with a soft damp cloth. Apply glass cleaner to cloth and do not apply directly to mirror.

**Never use abrasive cleaners as these could damage the finish.**

# INSTALLATION DIAGRAM

